

EPSON ACULASER® C2600 DRUM UNIT REMANUFACTURING INSTRUCTIONS



**EPSON ACULASER® C2600
COLOUR LASER PRINTER**



**EPSON ACULASER® C2600
DRUM UNIT**

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com

EPSON ACULASER C 2600 DRUM UNIT REMANUFACTURING INSTRUCTIONS

PRINTER TECHNICAL DATA

Part Numbers

AcuLaser C2600N - C11C585001BZ
AcuLaser C2600DN - C11C585001BT
AcuLaser C2600DTN - C11C585001BY

KEY FEATURES

Printing Technology

Laser

Resolution

Epson AcuLaser Colour 2400 RIT

Print Speed

Up to 30 pages per minute in black and white, 7.5 pages per minute in Colour A4

First Page Out

9.3sec in black and white, 15.3sec in colour

Processor

350MHz

Memory (Standard/Maximum)

64MB with Epson MiTech / up to 512MB max

Maximum Monthly Volume

120,000 pages in black and white mode; 48,000 pages in colour mode

PAPER HANDLING

Standard Paper Input

650 sheets (150 Multi-Purpose tray + 500-Sheet Paper Cassette)

Paper Weight

64 - 163 gsm

Optional Paper Handling

Up to one extra 500-Sheet Paper Cassette

Maximum Paper Input

1150 sheets (150 Multi-Purpose tray + 2 x 500-Sheet Paper Cassette)

Standard/Maximum Paper Output

250 sheets / 250 sheets

CONSUMABLES LIFE

Toner Cartridges

black: 5,000; colour: 5,000/2,000 pages under conditions of continuous printing at 5% coverage. Intermittent use may reduce page yield.

Toner Save Mode

Yes

Photo Conductor

40,000 pages in black and white, 10,000 pages in colour

ENVIRONMENTAL CONDITIONS

Temperature

Operation: 10 to 35 °C / Storage: 0 to 35 °C

Humidity

Operation: 15 to 85% RH / Storage: 10 to 85% RH (No condensation allowed)

DIMENSIONS AND WEIGHT (W x D x H mm, Kg)

*Weight including consumables)

Epson AcuLaser 2600N-C2600N

431 x 518 x 425 mm, 37 Kg

Epson AcuLaser 2600N-C2600DTN

447 x 518 x 538 mm, 43 Kg

REQUIRED TOOLS

Flat needle head player
Torx screw driver
Hook Tool (angled and straight)
Phillips Screwdriver
Flat-head Screwdriver (small and standard size)
X-Acto knife
Tester
Toner grabber
Cotton tip swap
Air compressor

REQUIRED SUPPLIES


Epson AcuLaser C 2600 Absolute Black® toner 155g
Epson AcuLaser C 2600 Absolute Cyan® toner 155g
Epson AcuLaser C 2600 Absolute Magenta® toner 155g
Epson AcuLaser C 2600 Absolute Yellow® toner 155g
Epson AcuLaser C 2600 Uni Drum® OPC (under development)
Epson AcuLaser C 2600 Smartchip® Black (under development)
Epson AcuLaser C 2600 Smartchip® Cyan (under development)
Epson AcuLaser C 2600 Smartchip® Magenta (under development)
Epson AcuLaser C 2600 Smartchip® Yellow (under development)
99% Isopropyl Alcohol
Distillate Water
Drum Lubricant (Yellow toner)
Conductive Grease
Friction Grease

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com



1. Release the drum unit turning the blue drum unit blocker lever one quarter counter clockwise.



2. We recommended to use the grey grid cleaner bar periodically to keep the corona clean and in excellent conditions of work.



3. Check and Clean if necessary the ozone filter with compressed air. Keep it horizontal and don't shake it before cleaning.




4. Drum unit front view.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com



5. Drum unit handle side view.



6. The waste toner sensor window is in the drum unit gear side view.



7. Remove the two Phillips screws from the black handle end cover.




8. Release the black end cap using a small flat head screwdriver to press the tab as shown.

www.uninetimaging.com/technical.asp


11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com



9. End cap and cartridge inside face view.



10. Release the plastic white clip from the drum shaft.



11. Drum shaft without the plastic white clip detail view.



12. On the other side of the drum, remove the plastic black drum gear cover.


www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com

© 2007 UniNet Imaging Inc. All Trademark names are property of their respective owners. Product brand names mentioned are intended to show compatibility only. UniNet Imaging does not guarantee or warrant downloaded information.




13. Pull out the OPC shaft softly.



14. Release the OPC as shown and cover it with a black cloth to avoid direct sunlight contact in case of recycling.




15. Release the gear end plate tab on the other side of the cartridge using a hook tool.



16. Remove the whole black lateral end cover lifting it as shown. Otherwise, the tabs can be damaged.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com



17. Unscrew both Phillips screws from the white plastic corona support on each side of the cartridge.



18. Release the white plastic corona supports on both sides.



19. Remove the two screws on the bottom black cover of the cartridge.




20. Release the black long end cap cover carefully.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com


© 2007 UniNet Imaging Inc. All Trademark names are property of their respective owners. Product brand names mentioned are intended to show compatibility only. UniNet Imaging does not guarantee or warrant downloaded information.




21. Remove the "corona" placed next to the wiper blade.



22. Notice the detail of lifting it from the left side.




23. Release the tension spring from the wiper blade holder using a hook tool until it gets free from the lower black tab.




24. Remove the lateral wiper blade blocking pin with a needle flat head pliers.

www.uninetimaging.com/technical.asp


11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com




25. Wiper blade blocking pin detail view.



26. Turn again the cartridge to remove the other pin.



27. Release the second wiper blade blocking pin with the same procedure.



28. Remove the wiper blade.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com

© 2007 UniNet Imaging Inc. All Trademark names are property of their respective owners. Product brand names mentioned are intended to show compatibility only. UniNet Imaging does not guarantee or warrant downloaded information.



29. Blow the hopper with compressed air to clean out any remaining waste toner.



30. Remove the bigger top black cover 6 screws as shown.



31. Remove the chamber cover.



32. Clean the waste hopper with compressed air.


www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com


© 2007 UniNet Imaging Inc. All Trademark names are property of their respective owners. Product brand names mentioned are intended to show compatibility only. UniNet Imaging does not guarantee or warrant downloaded information.



33. General view once cleaned. Clean as best as possible the plastic yield sensor window placed in the waste toner section to avoid a “full waste toner” message on printer’s display.



34. Clean the electrical contacts by means of a cotton tip swap with isopropyl alcohol.




35. Comb both wiper blade felt using a flathead screwdriver.



36. Clean the recovery blade with a cotton tip swap or a toner grabber with alcohol isopropyl mixed with distillate water. Be careful to don't damage or bend the blade since it would cause spotting.

www.uninetimaging.com/technical.asp


11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com




37. Install the foam of the top plastic black hopper cover through out its border. Help yourself with an small flat head screwdriver.



38. Reassemble it on place.



39. Clean the wiper blade blowing air and then using a toner grabber with distillate water in case of recycling it. Lubricate the recycled wiper blade as well as the new one with yellow toner.




40. Reinstall the wiper blade. First place both pins and then put the wiper blade tension spring using an angled hook tool.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com




41. Before installing the corona, clean it with air compressed as shown.



42. Reassemble the white plastic corona supports and then install the two screws on each side. Notice the screws have different sizes. The shorter one it would go on the other side of the cartridge in the picture.



43. Lubricate the new OPC with yellow toner.




44. Install the new lubricated drum, the "U"-shape clip, the axle with the new conductive grease lubricating the dedicated contact place and the plastic black drum gear cover. Pay attention to the inside drum contact, check it with a hook tool.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com



45. Cartridge view with its bottom cover uninstalled.



46. Place the long black bottom cover firstly from the left part as shown.



47. Place the gear end plate by left side to preserve the tabs.



48. Do the same with the other side handle cover.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com

© 2007 UniNet Imaging Inc. All Trademark names are property of their respective owners. Product brand names mentioned are intended to show compatibility only. UniNet Imaging does not guarantee or warrant downloaded information.



NOTES

49. Give the cartridge the last cleaning retouching and in case of installing a recycled drum, brush the gears with a hair cut brush to eliminate all residual toner.

www.uninetimaging.com/technical.asp

11124 Washington Blvd., Culver City, California USA 90232 • Ph +1 310 280 9620 • Fx +1 310 280 0533 • techsupport2@uninetimaging.com